

Removing chewing gum

with freeze spray



	Description	
Definition / objective	Removing chewing gum from surfaces and floor coverings using freeze spray. Suitable for textile, hard or elastic floor coverings, carpets or upholstery.	
Preparatory work	Select suitable products to match the surface to be cleaned (type / square metres) and the typ soiling.	e o
	Put up the warning sign.	
	Thoroughly remove any loose dirt (dry vacuuming or brush vacuuming).	
Main task	Generously spray the chewing gum with freeze spray (chewing gum remover).	
	Wait until the chewing gum is frozen.	
	Use the blunt plastic spatula to loosen or break up the frozen chewing gum while vacuuming it away (dry vacuuming).	:
	Repeat the process until the chewing gum is removed.	
	Use a suitable stain remover (stain removal method) if the chewing gum leaves a colour stain.	
Final steps	Check the power cable for visible damage, clean the cable and roll it up loosely towards the plug.	
	Remove the warning sign.	
	Dispose of any waste.	
	Clean the cleaning equipment and replace as needed.	
Comments	 Wear the personal protective equipment (PPE) required by company regulations, safety data sheets and / or instructions for use. Always check in advance which product meets your requirements (see Wetrok Cleaning & Care Instructions) Wetrok AG accepts no liability for damage caused by improper use or incorrect product selection. 	